

STAND BY FOR TELEPORTATION.

The Teleporter Adventures has been designed as a shared experience. Please read the *Sammy the Space Koala* book together and only Teleport when indicated.


To begin your adventure, follow these instructions:



1. Download The Teleporter Adventures app. To avoid data charges, please use a secure Wi-Fi network. Leave the download running and go to next step.



2. Read the first chapter of *Sammy the Space Koala*. When you see the icon to the left, it's time to Teleport! To set up your Teleporter headset, please:



a) Remove the cover



b) Open the lid



c) Open up the two flaps, pull them towards you and fasten them to the sides of the Teleporter using the Velcro. Remove protective film over lenses.


d) When you open the app for the first time, turn your phone so it's landscape. Select this icon  and follow the steps to switch your viewer. When prompted, you will need to scan the QR code below.



e) Place your smartphone into the Teleporter. Ensure the phone is centred in the headset and the volume is turned up.



f) Close the lid tightly so that your phone does not slip out.



g) Whilst playing, you can press the silver button to select an item, or stare at it (hold steady until the green circle completes).

3. After each Teleporter adventure, please go back to reading the storybook together.

Important safety information

Teleportation is not for everyone. If your child feels unwell, please stop immediately. The app in virtual reality mode is not suitable for children with epilepsy, or under the age of five. Please stay seated while Teleporting. Parental supervision is recommended. If you're in doubt about any of the above or continue to experience nausea or discomfort, please consult your GP.

Additional settings and tips

During Teleportation, remind your child to look all around – even behind them! If they get lost and can't remember which way is forward, they can look down and select the 'Reset' icon .

There is also a 'Settings' icon  which allows you to:

- Reset position – reset the direction so you face forward.
- VR Mode Off – experience the app as a full screen interactive game, so you can see what your child is seeing.
- Reset game data – reset the experience for another child.

Now take a seat, you're ready to Teleport!

Things you should know: 'The Teleporter Adventures' app (the app) is only compatible with the following smartphones: iPhone 5 (iOS 6) and above, Android 4.4.3 (Android) and above. Parental supervision required. Not recommended for children under five. Download the app over a secure Wi-Fi network to avoid data charges. Remain seated at all times, be careful smartphone doesn't slip out of headset, and do not use for more than five minutes at a time. Do not use the app if you have epilepsy, and stop using immediately if you feel nauseous. Apple and the Apple logo are trademarks of Apple Inc., registered in the US and other countries. App Store is a service mark of Apple Inc. Android and Google Play are trademarks of Google Inc. Commonwealth Bank of Australia ABN 48 123 123 124 Australian credit licence 234945.